

Chinook Maintenance Check-List

	<u>Before every trip, at least twice a year</u>
<input type="checkbox"/>	Check tires and tire pressure (Use no more than 5 lbs over posted Ford/Chevy pressure listed in door)
<input type="checkbox"/>	Check headlights and brake lights
<input type="checkbox"/>	Clear roof of any debris
<input type="checkbox"/>	Close and lock all doors and storage compartments
<input type="checkbox"/>	Retract all slides, jacks and awnings
<input type="checkbox"/>	Unplug all appliances and electrical
<input type="checkbox"/>	Secure all loose items
	<u>Monthly</u>
<input type="checkbox"/>	Check the water levels of the battery (If the coach is left plugged in, batteries are charged continuously. Temperature generated while charging causes loss of water.) Refill With distilled water only.
<input type="checkbox"/>	Run the generator with a 50% load at least 2 hours
	<u>Every three months</u>
<input type="checkbox"/>	Check LP gas lines for leaks with soap solution or leak detector
<input type="checkbox"/>	Test the smoke alarm and carbon monoxide/LP detectors
<input type="checkbox"/>	Check operations of windows and hardware; clean weep holes, tracks
<input type="checkbox"/>	Clean air conditioner filters
<input type="checkbox"/>	Tighten battery cables
<input type="checkbox"/>	Inspect the slide-out for proper seal
<input type="checkbox"/>	Change the smoke detector battery
<input type="checkbox"/>	Check gas appliances
<input type="checkbox"/>	Have LP system checked
<input type="checkbox"/>	Check for deterioration to caulked areas
<input type="checkbox"/>	Check for water leaks or water damage - common areas back closet, step area, under cooktop/oven cabinet; by sink. A/C can leak into shell will either drip or run toward antenna/upper cabinet.
<input type="checkbox"/>	Sanitize the fresh water system
<input type="checkbox"/>	Wax motorhome with wax for fiberglass
	<u>Once a year</u>
<input type="checkbox"/>	Water Heater Safety Valve - Look for the little handle after the cover is removed; If no hot water at the time, and you have water connected, raise the handle up. Flushes valve out. Water will spurt out!!!!